

This guideline describes the installation of the C-MOR Video Surveillance camera licenses. Camera licenses can be ordered by the C-MOR web.

C-MOR installs always as a C-MOR3, with 3 IP cameras. Activating more cameras requires the installation of a camera license code. This code is usually sent by email from C-MOR.


The following information is required for activating more cameras in C-MOR; the username and password, as well as the license key self. Usually you get an email with this information. This looks like for example

Username: your_personal_login

Password: 123abc456


License: 1234abcde67899fghij

Log in to C-MOR for the camera license upgrade via web. For example use http://192.168.1.2 if you use the default IP address of C-MOR. Log in as user "admin" with the password "admin". Click on "System Administration" menu on top.






Scroll down to the menu "License Upgrade":



The number of activated camera licenses is shown on top. Enter your license information data which you received from C-MOR by email:





After applying the correct information the C-MOR web shows directly how many licenses have been activated:



Reboot C-MOR now by pressing the button "System Restart".

A warning message pops up.



Click "ok" to restart C-MOR. After the reboot the just granted licenses are activated. After the reboot C-MOR shows all added cameras:





The camera update is done!